

Time and temperature resolved resistivity recovery of irradiated metals

E. Mitsi¹, A. Theodorou^{1,2}, Z. Kotsina³, M. Axiotis³, G. Apostolopoulos¹

¹Institute of Nuclear and Radiological Science and Technology, Energy and Safety NCSR "Demokritos", Greece ²Section of Solid State Physics, Department of Physics, National and Kapodistrian University of Athens, Greece ³Tandem Accelerator Laboratory, Institute of Nuclear Physics, NCSR "Demokritos", Greece









This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the Euratom research and training programme 2014-2018 and 2019-2020 under grant agreement No 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.

Introduction / Motivation



Defects form in crystals under **high energy irradiation**

- Most important: vacancies and self interstitial atoms-SIAs
- Cause degradation of physical & mechanical properties
- Fundamental defect studies are important for developing materials for next-generation energy systems.



Schematic illustration of irradiation defects [Knaster et al. Nat. Phys. 2016]



Creep & fracture due to irradiation

Introduction / Motivation



- Electrical resistivity is a key method for defect studies
 - Highly sensitive to changes in defect population
 - Can be measured *in-situ* during and after irradiation
 - Resistivity recovery is observed during post-irradiation, isothermal or isochronal annealing
 - Can provide rich information: defect interaction, migration annihilation etc.
- Drawbacks:
 - Difficult to analyze / interpret
 - Assumptions needed in order to obtain defect data from measurements

Aim / Methodology



- <u>Our aim</u> is to employ modern digital measurement techniques in order to:
 - Improve the information content & resolution of resistivity recovery measurements
 - Reduce the assumptions needed for analyzing the results

Methodology:

- Realize a complex post-irradiation annealing program that combines isochronal and isothermal aspects
- Thus obtaining time & temperature resolved resistivity recovery measurements

Experimental Setup and Details



- **<u>Samples</u>**: W single crystal (111) oriented
- Irradiation Conditions:
 - Irradiation conducted at 5 MV TANDEM accelerator of NCSR 'Demokritos'
 - Facility utilized was IR²
 - 7 MeV proton beam
 - Temperature during irradiation was kept at T= 7 K



 IR^2 beam line overview



 IR^2 main components

E. Mitsi et. al. | HNPS2021 | Athens | 24-25 September 2021 | Page 5

Time resolved resistivity recovery



- Resistivity recovery: Utilizing isothermal and isochronal annealing
- Annealing Conditions:
 - 8 < T < 70 K
 - $\Delta T/T = 0.04$
 - At each temperature, 8 resistivity measurements for Δt=1 min



Resistivity evolution over time

Experimental Results





Traditional Isochronal Annealing

- One measurement per temperature for constant holding time
- Result: $\rho(T)$

New Method

- 8 measurements per temperature at 1 min intervals
- Result: $\rho(T, t)$
- Significantly increased information content
- May give insight into the defect kinetics mechanisms



Experimental Results





Display of resistivity recovery through time and temperature video link

E. Mitsi et. al. | HNPS2021 | Athens | 24-25 September 2021 | Page 8

Data Analysis



- Here we present the most simple one
- Assuming 1st order kinetics, $\frac{dN}{dt} = -\frac{N}{\tau} \Rightarrow N(t) = N_0 e^{-t/\tau}$

•
$$\rho(t,T) - \rho(0,T) = A \cdot N_0 [e^{-t/\tau} - 1] = A \cdot N_0 [e^{-\frac{t}{\tau(T)}} - 1]$$



Different kinetic models will be tested in order to determine physical parameters, and compare different models

Conclusions



- A new method for conducting resistivity recovery experiments is presented
- Combining isochronal & isothermal aspects in the annealing process we obtain time & temperature resolved resistivity recovery
- This is realized by the highly automated digital measurement system of IR^2 facility
- A test measurement is presented on a proton irradiated W single crystal
- Examples of data analysis show the new possibilities offered by this method

Acknowledgements



 Scientific & technical personnel at the TANDEM Accelerator, NCSR-D

• Thank you for your attention ...



This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the Euratom research and training programme 2014-2018 and 2019-2020 under grant agreement No 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.